

INSTALLATION AND OPERATING INSTRUCTIONS

TWT-SLM • TWT-SLMC • TWT-SLMG



INSTALLATION: *Easy as 1-2-3!*

1. Remove the existing showerhead from the shower arm.
2. Remove the blue plug from the Slim-Line Shower Filter.
3. Screw the Slim-Line Shower Filter onto the shower arm Do Not Over Tighten!

OPERATION: *Before entering the shower.*

4. Run the shower water at "Hot".
5. After hot water is flowing through filter, cool to desired temperature.

KDF-GAC CARTRIDGE REPLACEMENT:

Replace within 1 year according to individual water conditions.

1. Unscrew the shower filter housing.
2. Remove the used cartridge and replace with a new cartridge [TWT-SLM-RC]. It is important that the O-ring inside each of the halves is properly seated in the O-ring groove.
Screw the housings together.

